

WOMENS FITTING CHART									
EXTRA NARROW	LAST SIZE (MM)	2	3	4	5	6	7	8	9
	Joint Width	79	81	83	85	87	89	91	93
	Joint Circ.	201-219	207-225	214-232	220-238	226-244	233-251	239-257	245-263
	Instep Circ.	197-215	203-221	210-228	216-234	222-240	229-247	235-253	241-259
	Toe Depths	31	32	33	34	35	36	37	38
NARROW	Joint Width	83	85	87	89	91	93	95	97
	Joint Circ.	209-227	215-233	221-239	227-245	233-251	240-258	246-264	252-270
	Instep Circ.	203-221	209-227	215-233	221-239	227-245	233-251	239-257	245-263
	Toe Depths	31	32	33	34	35	36	37	38
STANDARD	Joint Width	89	91	93	95	97	99	101	103
	Joint Circ.	224-242	230-248	236-254	242-260	248-266	254-272	260-278	266-284
	Instep Circ.	210-228	216-234	222-240	228-246	234-252	241-259	247-265	253-271
	Toe Depths	31	32	33	34	35	36	37	38
WIDE	Joint Width	94	96	98	100	102	104	106	108
	Joint Circ.	234-252	240-258	246-264	252-270	258-276	265-283	271-289	277-295
	Instep Circ.	216-234	222-240	228-246	235-253	241-259	248-266	254-272	260-278
	Toe Depths	31	32	33	34	35	36	37	38
STANDARD EXTRA DEEP	Joint Width	89	91	93	95	97	99	101	103
	Joint Circ.	236-254	242-260	248-266	254-272	260-278	266-284	272-290	278-296
	Instep Circ.	222-240	228-246	234-252	240-258	246-264	253-271	259-277	265-283
	Toe Depths	37	38	39	40	41	42	43	44
WIDE EXTRA DEEP	Joint Width	94	96	98	100	102	104	106	108
	Joint Circ.	246-264	252-270	258-276	264-282	270-288	277-295	283-301	289-307
	Instep Circ.	228-246	234-252	240-258	246-265	253-271	260-278	266-284	272-290
	Toe Depths	37	38	39	40	41	42	43	44
BOOTS	Height	98	100	102	104	106	108	110	112
	Circ.	189	196	203	210	217	224	231	238

